



600 3rd Ave, Laval, QC, H7R 4J4
 Tel: (514)631-2173
 Fax:(450)627-2199
 email: info@aeroneuf.com



BEECH KING AIR 200 CAPABILITY LIST

Part Number	Manufacturer	Description	Aircraft
121544	Edcliff	Oil Pressure Transducer	King Air 200
142101	Edcliff	Oil Pressure Transducer	King Air 200
160503	Beechcraft	Altimeter	King Air 200
521633	Ametek/Weston	T.I.T. Indicator	King Air 200
521880	Ametek/Weston	T.I.T. Indicator	King Air 200
521942	Ametek/Weston	T.I.T. Indicator	King Air 200
522082	Ametek/Weston	Oil Pressure/Temp Indicator	King Air 200
522325	Ametek/Weston	T.I.T. Indicator	King Air 200
522333	Ametek/Weston	Oil Pressure/Temp Indicator	King Air 200
09007-0168	Aerosonic	Suction Gage	King Air 200
100-0034-04	R.C.Allen	Prop Tach Indicator	King Air 200
100-0034-10	R.C.Allen	Turbine Tach Indicator	King Air 200
100-380006-129	Beechcraft	Fuel Quantity Indicator	King Air 200
100-380006-47	Beechcraft	Fuel Quantity Indicator	King Air 200
100-384054-1	Beechcraft	I.V.S.I.	King Air 200
100-384093-1	Beechcraft	Wing Tip Fuel Quantity Indicator	King Air 200
101-364291-1	Beechcraft	Landing Gear Control Unit	King Air 200
101-384008-3	Beechcraft	Torque Indicator	King Air 200
101-384009-1	Beechcraft	Fuel Flow Indicator	King Air 200
101-384029-1	Beechcraft	Flap Position Indicator	King Air 200
101-384030-3	Beechcraft	Airspeed Indicator	King Air 200
101-384031-1	Beechcraft	Airspeed Indicator	King Air 200
101-384074-3	Beechcraft	Airspeed Indicator	King Air 200
101-384092-1	Beechcraft	Clock, 24 Hour	King Air 200
101-384101-1	Beechcraft	Airspeed Indicator	King Air 200
101-384106-1	Beechcraft	DC Volt/Load Indicator	King Air 200
101-384106-3	Beechcraft	DC Volt/Load Indicator	King Air 200
101-384107-1	Beechcraft	AC Volt/Frequency Meter	King Air 200
101-384107-3	Beechcraft	AC Volt/Frequency Meter	King Air 200
101-384120-5	Beechcraft	Gyro Horizon AC	King Air 200
101-384122-5	Beechcraft	Oil Pressure/Temp Indicator	King Air 200
101-384122-7	Beechcraft	Oil Pressure/Temp Indicator	King Air 200
101-384133-1	Beechcraft	Suction Gage	King Air 200
101-384150-7	Beechcraft	Fuel Quantity Indicator	King Air 200
101-384151-5	Beechcraft	Fuel Quantity Indicator	King Air 200
101-389003-1	Beechcraft	Oil Pressure Transducer	King Air 200
101-389017-9	Beechcraft	Prop Ammeter	King Air 200
101-500053-5	Beechcraft	Turn & Slip Indicator 3" DC Elect	King Air 200
101-530508-13	Beechcraft	Magnetic Compass	King Air 200
101-530508-3	Beechcraft	Magnetic Compass	King Air 200
101735-01563	Aerosonic	Altimeter	King Air 200
117-384019-3	Beechcraft	Fuel Quantity Indicator	King Air 200

1441-03	Aero Mach Labs	Airspeed Indicator	King Air 200
1509-01	Aero Mach Labs	Airspeed Indicator	King Air 200
152C208M	Horizon Aerospace	T.I.T. Indicator	King Air 200
152C208U	Horizon Aerospace	T.I.T. Indicator	King Air 200
1592-19	Beechcraft	O.A.T. Indicator	King Air 200
16050SL	Beechcraft	Altimeter	King Air 200
1652-6AW-B6-1	Bendix	Cabin Rate of Climb Indicator	King Air 200
1U262-001-11	Sigma-Tek/Edo-Aire	Directional Gyro Air Driven	King Air 200
20140-01159	Aerosonic	Airspeed Indicator	King Air 200
20B380-1	A.I.D.	Turn & Slip Indicator 2" Air	King Air 200
210-5B	J.E.T/A.I.M.	Directional Gyro	King Air 200
22-112-03-2A	Beechcraft	Pneumatic Pressure Gage	King Air 200
22-279-03A	Sigma-Tek/Garwin	Prop Tach Indicator	King Air 200
22-955-01	Beechcraft	Cabin Air Temp Indicator	King Air 200
23-424-01	Sigma-Tek/Garwin	Turn & Slip Indicator 3" DC Elect	King Air 200
23-501-016-1	Sigma-Tek/Edo-Aire	Gyro Horizon Air Driven	King Air 200
267-901-003	Parker/Gull Airborne	Fuel Quantity Indicator	King Air 200
267-917-001	Parker/Gull Airborne	Fuel Flow Indicator	King Air 200
26B226-1	A.I.D.	Flap Position Indicator	King Air 200
27B411-1	A.I.D.	Suction Gage	King Air 200
2800-26	Mid-Continent/General D	Turn & Slip Indicator 3" DC Elect	King Air 200
2800-7315	Mid-Continent/General D	Turn & Slip Indicator 2" DC Elect	King Air 200
29B3000-19	A.I.D.	T.I.T. Indicator	King Air 200
300-903-006	Parker/Gull Airborne	Fuel Quantity Indicator	King Air 200
311-11	A.I.D.	Turn & Slip Indicator 3" Air	King Air 200
35060-0116	Aerosonic	Cabin Rate of Climb Indicator	King Air 200
3571212-0053	Bendix	Fuel Flow Indicator	King Air 200
3571262-7303	Bendix	Prop Tach Indicator	King Air 200
3571281-8104	Bendix	Turbine Tach Indicator	King Air 200
4000B-10	Sigma-Tek/Edo-Aire	Directional Gyro Air Driven	King Air 200
400-18-1	Beechcraft	Altimeter	King Air 200
414-183771-27	United Instruments	Altimeter	King Air 200
41SG107-200G-1	Kulite	Oil Pressure Transducer	King Air 200
437-4-1	Beechcraft	Pneumatic Pressure Gage	King Air 200
5006-1028	Insco	T.I.T. Indicator	King Air 200
500ECF	J.E.T/A.I.M.	Gyro Horizon AC	King Air 200
50-364314-601	Beechcraft	Flap Position Switch Assy	King Air 200
50-364314-609	Beechcraft	Flap Position Switch Assy	King Air 200
50-364314-613	Beechcraft	Flap Position Switch Assy	King Air 200
50-380023-1	Beechcraft	Turn & Slip Indicator 3" Air	King Air 200
50-380024	Beechcraft	Turn & Slip Indicator 3" DC Elect	King Air 200
50-380026-1	Beechcraft	Cabin Temperature Gage	King Air 200
50-380034-3	Beechcraft	Turbine Tach Indicator	King Air 200
50-380035-5	Beechcraft	Prop Tach Indicator	King Air 200
50-380045	Beechcraft	Cabin Rate of Climb Indicator	King Air 200
50-380045	Beechcraft	Cabin Rate of Climb Indicator	King Air 200
50-380046-17	Beechcraft	Altitude & Differential Pressure	King Air 200
50-380067	Beechcraft	Loadmeter	King Air 200
50-380091	Beechcraft	Prop Sync Indicator	King Air 200
50-380105-1	Beechcraft	Pneumatic Pressure Gage	King Air 200
50-384042-9	Beechcraft	Suction Gage	King Air 200
50-384073	Beechcraft	V.S.I.	King Air 200
50-384077-1	Beechcraft	O.A.T. Indicator	King Air 200
50-384203-3	Beechcraft	Gyro Horizon Air Driven	King Air 200
50-384204	Beechcraft	Directional Gyro	King Air 200

50-384205	Beechcraft	Directional Gyro Air Driven	King Air 200
50-384210-1	Beechcraft	Clock	King Air 200
50-389102-19	Beechcraft	T.I.T. Indicator	King Air 200
509-0001-904	J.E.T/A.I.M.	Turn & Slip Indicator 3" DC Elect	King Air 200
55035-0103-13	Aerosonic	Altitude & Differential Pressure	King Air 200
55610-1	Beechcraft	Cabin Temperature Gage	King Air 200
556-10-1	Beechcraft	Cabin Air Temp Indicator	King Air 200
558-1	Instruments, Inc.	Flap Position Indicator	King Air 200
5609-03	Aero Mach Labs	Turbine Tach Indicator	King Air 200
5609-05	Aero Mach Labs	Prop Tach Indicator	King Air 200
562-693	Hickok	Prop Ammeter	King Air 200
562-898	Hickok	DC Volt/Load Indicator	King Air 200
562-937	Hickok	Prop Ammeter	King Air 200
562-974	Hickok	DC Volt/Load Indicator	King Air 200
563-241	Hickok	Oil Pressure/Temp Indicator	King Air 200
563-242	Hickok	Oil Pressure/Temp Indicator	King Air 200
570-529	Hickok	AC Volt/Frequency Meter	King Air 200
570-531	Hickok	AC Volt/Frequency Meter	King Air 200
5803-11	Aero Mach Labs	T.I.T. Indicator	King Air 200
5803-23	Aero Mach Labs	T.I.T. Indicator	King Air 200
5803-29	Aero Mach Labs	T.I.T. Indicator	King Air 200
5803-31	Aero Mach Labs	T.I.T. Indicator	King Air 200
58-380069-5	Beechcraft	Altimeter	King Air 200
5934A-A.106	United Instruments	Altimeter	King Air 200
6501-1046	Insco	Prop Tach Indicator	King Air 200
6501-1047	Insco	Turbine Tach Indicator	King Air 200
7040-B.4	United Instruments	V.S.I.	King Air 200
7130-C.44	United Instruments	I.V.S.I.	King Air 200
81-101-1	Meggitt/Ragen	Fuel Quantity Indicator	King Air 200
81-101-3	Meggitt/Ragen	Fuel Quantity Indicator	King Air 200
81-101-5	Meggitt/Ragen	Fuel Quantity Indicator	King Air 200
86000-0177	Aerosonic	Clock, 24 Hour	King Air 200
8DJ81AAP1	Ametek/G.E.	Prop Tach Indicator	King Air 200
8DJ81CCY4	Ametek/G.E.	Turbine Tach Indicator	King Air 200
8TJ9PFF45	Ametek/G.E.	Flap Position Transmitter	King Air 200
9032-1009	Insco	Wing Tip Fuel Quantity Indicator	King Air 200
90-380007-9	Beechcraft	Prop Ammeter	King Air 200
90-380009-2	Beechcraft	Fuel Flow Indicator	King Air 200
90-384026-11	Beechcraft	T.I.T. Indicator	King Air 200
90-384026-23	Beechcraft	T.I.T. Indicator	King Air 200
90-384026-29	Beechcraft	T.I.T. Indicator	King Air 200
90-384026-31	Beechcraft	T.I.T. Indicator	King Air 200
91-380018-1	Beechcraft	Turn & Slip Indicator 2" Air	King Air 200
91-380019-1	Beechcraft	Turn & Slip Indicator 2" DC Elect	King Air 200
9550B	United Instruments	Turn & Slip Indicator 2" DC Elect	King Air 200
99-380069-5	Beechcraft	Altimeter	King Air 200
99-384039	Beechcraft	Altimeter	King Air 200
A11579	Beechcraft	Prop Ammeter	King Air 200
A1620-03	R.C.Allen	Turn & Slip Indicator 2" DC Elect	King Air 200
A4530M9-5	Eaton	Landing Gear Control Unit	King Air 200
AN5786-1	Ametek/G.E.	Flap Position Transmitter	King Air 200
AN5786-1	Liquidometer/BFG/Simn	Flap Position Transmitter	King Air 200
AT4220A5	Astrotech	Clock, Control Wheel	King Air 200
B365-5	A.I.D.	Prop Tach Indicator	King Air 200
B366-3	A.I.D.	Turbine Tach Indicator	King Air 200

B381	A.I.D.	Turn & Slip Indicator 3" DC Elect	King Air 200
B410-1	A.I.D.	Pneumatic Pressure Gage	King Air 200
B411-9	A.I.D.	Suction Gage	King Air 200
EA173E-2	Liquidometer/BFG/Simn	Flap Position Transmitter	King Air 200
G4003	R.C.Allen	Turn & Slip Indicator 3" DC Elect	King Air 200
LC-2A-5	Astrotech	Clock, Control Wheel	King Air 200
MD105-1	Mid-Continent	De-Ice Pressure Gage	King Air 200
MD106-1	Mid-Continent	DC Volt/Load Indicator	King Air 200
MD127-1	Mid-Continent	Suction Gage	King Air 200
RC30V101	Aerosonic	I.V.S.I.	King Air 200
RCA41-06	R.C.Allen	Turbine Tach Indicator	King Air 200
RCA42-01	R.C.Allen	Prop Tach Indicator	King Air 200
SLZ9635	Teledyne	I.V.S.I.	King Air 200
SR-2AM	Ametek/U.S.Gauge	Torque Indicator	King Air 200