



600 3rd Ave, Laval, QC, H7R 4J4
 Tel: (514)631-2173
 Fax:(450)627-2199
 email: info@aeroneuf.com



BOEING 737 CAPABILITY LIST

| Part Number | Manufacturer | Description |
|-----------------|---------------------|---------------------------------------|
| 10031-0000-01 | Simmonds Precision | Engine Oil Quantity Indicator |
| 10033-0000-02 | Simmonds Precision | Hydraulic Oil Quantity Indicator |
| 10034-0000-02 | Simmonds Precision | Hydraulic Oil Quantity Indicator |
| 10037-1000-0151 | Simmonds Precision | Fuel Quantity Indicator |
| 10037-1000-0152 | Simmonds Precision | Fuel Quantity Indicator |
| 10037-1000-0153 | Simmonds Precision | Fuel Quantity Indicator |
| 10037-1000-0154 | Simmonds Precision | Fuel Quantity Indicator |
| 10037-1000-0155 | Simmonds Precision | Fuel Quantity Indicator |
| 10037-1000-0156 | Simmonds Precision | Fuel Quantity Indicator |
| 10037-1000-0157 | Simmonds Precision | Fuel Quantity Indicator |
| 10037-1000-0158 | Simmonds Precision | Fuel Quantity Indicator |
| 10037-1000-0159 | Simmonds Precision | Fuel Quantity Indicator |
| 10037-1000-0160 | Simmonds Precision | Fuel Quantity Indicator |
| 10037-1000-0161 | Simmonds Precision | Fuel Quantity Indicator |
| 10037-1000-0162 | Simmonds Precision | Fuel Quantity Indicator |
| 10037-1000-0163 | Simmonds Precision | Fuel Quantity Indicator |
| 10037-1000-0164 | Simmonds Precision | Fuel Quantity Indicator |
| 10037-1000-0165 | Simmonds Precision | Fuel Quantity Indicator |
| 10037-1000-0166 | Simmonds Precision | Fuel Quantity Indicator |
| 10051-0000-01 | Simmonds Precision | Engine Oil Quantity Indicator |
| 10054-0000-01 | Simmonds Precision | Engine Oil Quantity Indicator |
| 10066-0000-01 | Simmonds Precision | Fuel Quantity Indicator |
| 114.029 | Rogerson/Kratos | Position Indicator |
| 124.835 | Rogerson/Kratos | Frequency Meter |
| 13CT-0213-A | Astro Instruments | Transformer, Control Surface Position |
| 13TX-0115-A | Astro Instruments | Transmitter, Control Surface Position |
| 146895-01-01 | Smiths/Lear Siegler | Total Air Temperature Indicator |
| 147LC10 | Horizon Aerospace | Gen. Drive Oil Temperature Indicator |
| 149LA6 | Horizon Aerospace | DC Ammeter Indicator |
| 149LA7 | Horizon Aerospace | AC Ammeter Indicator |
| 149LF10 | Horizon Aerospace | Frequency Indicator |
| 149LV11 | Horizon Aerospace | AC Voltmeter |
| 149LV8 | Horizon Aerospace | DC Voltmeter Indicator |
| 152BL702 | Horizon Aerospace | Temperature Indicator |
| 152BL702A | Horizon Aerospace | Temperature Indicator |
| 152BL706 | Horizon Aerospace | Temperature Indicator |
| 152BL801 | Horizon Aerospace | Temperature Indicator |
| 152BL801A | Horizon Aerospace | Temperature Indicator |
| 152BL801C | Horizon Aerospace | Temperature Indicator |
| 152BL801D | Horizon Aerospace | Temperature Indicator |
| 152BL801E | Horizon Aerospace | Temperature Indicator |

| | | |
|---------------|--------------------|--------------------------------------|
| 152BL802A | Horizon Aerospace | Temperature Indicator |
| 152BL802D | Horizon Aerospace | Temperature Indicator |
| 152BL803 | Horizon Aerospace | Temperature Indicator |
| 152BL803A | Horizon Aerospace | Temperature Indicator |
| 152LMA18 | Horizon Aerospace | Temperature Indicator |
| 152LMA22 | Horizon Aerospace | Temperature Indicator |
| 152LMA23 | Horizon Aerospace | Temperature Indicator |
| 154LUA104 | Horizon Aerospace | Valve Position Indicator |
| 162BL502 | Horizon Aerospace | Temperature Indicator |
| 162BL505 | Horizon Aerospace | Temperature Indicator |
| 162BL701 | Horizon Aerospace | Temperature Indicator |
| 162BL704C | Horizon Aerospace | Temperature Indicator |
| 162BL704L | Horizon Aerospace | Temperature Indicator |
| 162BL801 | Horizon Aerospace | Temperature Indicator |
| 162BL802 | Horizon Aerospace | Temperature Indicator |
| 162BL802A | Horizon Aerospace | Temperature Indicator |
| 162BL803 | Horizon Aerospace | Temperature Indicator |
| 162BL803A | Horizon Aerospace | Temperature Indicator |
| 162BL902 | Horizon Aerospace | Temperature Indicator |
| 162BL903 | Horizon Aerospace | Temperature Indicator |
| 162BL906 | Horizon Aerospace | Temperature Indicator |
| 163BL511 | Horizon Aerospace | Temperature Indicator |
| 163CV59 | Horizon Aerospace | Water & Waste Quantity Indicator |
| 163CV64 | Horizon Aerospace | Water & Waste Quantity Indicator |
| 163LCP80 | Horizon Aerospace | Brake Accumulator Pressure Indicator |
| 1680-4U-A2 | Courter | Rate of Climb Indicator |
| 1783867-11 | Honeywell/Sperry | Servo Amplifier |
| 1783867-3 | Honeywell/Sperry | Servo Amplifier |
| 1784460-655 | Honeywell/Sperry | Gyrosyn Compass Indicator |
| 1784460-657 | Honeywell/Sperry | Gyrosyn Compass Indicator |
| 18-1299 | Courter | Flap Position Ind |
| 18-1299-6 | Courter | Flap Position Indicator |
| 18-1299-6-2 | Courter | Flap Position Indicator |
| 182936 | Ametek/Weston | Oxygen Pressure Indicator |
| 182972 | Ametek/Weston | Oxygen Pressure Indicator |
| 185.076 | Rogerson/Kratos | AC Ammeter Indicator |
| 1925179-5 | Bendix | Radio Magnetic Indicator |
| 1925179-6 | Bendix | Radio Magnetic Indicator |
| 1925179-7 | Bendix | Radio Magnetic Indicator |
| 1925179-9 | Bendix | Radio Magnetic Indicator |
| 1G11-3 | Parker Aerospace | Suction Gauge Indicator |
| 1G386 | C.C.S. | Pressure Switch |
| 20041-0000-03 | Simmonds Precision | Liquid Qty Engine Oil Transmitter |
| 2061-14-1 | Smiths Industries | Flap Position Indicator |
| 2581942-901 | Honeywell/Sperry | Roll Rack Self-Test Panel |
| 2581942-903 | Honeywell/Sperry | Roll Rack Self-Test Panel |
| 2587317-653 | Honeywell/Sperry | Gyrosyn Compass Indicator |
| 2587317-655 | Honeywell/Sperry | Gyrosyn Compass Indicator |
| 2587335-11 | Honeywell/Sperry | Vertical Gyro |
| 2587335-111 | Honeywell/Sperry | Vertical Gyro |
| 2587335-112 | Honeywell/Sperry | Vertical Gyro |
| 2587335-113 | Honeywell/Sperry | Vertical Gyro |

| | | |
|-----------------|--------------------|----------------------------------|
| 2587335-12 | Honeywell/Sperry | Vertical Gyro |
| 2588282-655 | Honeywell/Sperry | Gyrosyn Compass Indicator |
| 2588282-657 | Honeywell/Sperry | Gyrosyn Compass Indicator |
| 2588302-1 | Honeywell/Sperry | Directional Gyro |
| 2588302-3 | Honeywell/Sperry | Directional Gyro |
| 2588302-4 | Honeywell/Sperry | Directional Gyro |
| 2588302-5 | Honeywell/Sperry | Directional Gyro |
| 2588369-903 | Honeywell/Sperry | Attitude Director Indicator |
| 2588369-905 | Honeywell/Sperry | Attitude Director Indicator |
| 2588424-902 | Honeywell/Sperry | Rate of Turn Rack |
| 2588424-906 | Honeywell/Sperry | Rate of Turn Rack |
| 2589479-901 | Honeywell/Sperry | Roll Control Channel |
| 2589479-902 | Honeywell/Sperry | Roll Control Channel |
| 2CM9ABY7 | Ametek/G.E. | Tachometer Generator |
| 36140-1AF25B1 | Bendix | Radio Magnetic Indicator |
| 36140-1AF25B3 | Bendix | Radio Magnetic Indicator |
| 36140-1AJ25B1 | Bendix | Radio Magnetic Indicator |
| 36148-1AJ25A1 | Bendix | Radio Magnetic Compass Indicator |
| 36148-1AJ25A2 | Bendix | Radio Magnetic Compass Indicator |
| 36154-1AF25A1 | Bendix | Radio Magnetic Compass Indicator |
| 36154-1AF25B1 | Bendix | Radio Magnetic Compass Indicator |
| 36154-1AJ25A1 | Bendix | Radio Magnetic Compass Indicator |
| 36154-1AJ25B1 | Bendix | Radio Magnetic Compass Indicator |
| 36154-1AJ33B1 | Bendix | Radio Magnetic Compass Indicator |
| 361551AF25A1 | Bendix | Radio Magnetic Compass Indicator |
| 36155-1AF25A2 | Bendix | Radio Magnetic Compass Indicator |
| 36155-1AJ25A1 | Bendix | Radio Magnetic Compass Indicator |
| 36158-1AF-25-A1 | Bendix | Radio Magnetic Compass Indicator |
| 36158-1AJ-25B1 | Bendix | Radio Magnetic Compass Indicator |
| 3800 | Thales/Sextant | Chronometric Tachometer |
| 391041-023 | Simmonds Precision | Compensator Assembly |
| 391041-026 | Simmonds Precision | Compensator Assembly |
| 391041-027 | Simmonds Precision | Compensator Assembly |
| 393020-003 | Simmonds Precision | Fuel Quantity Indicator |
| 393020-004 | Simmonds Precision | Fuel Quantity Indicator |
| 393020-012 | Simmonds Precision | Fuel Quantity Indicator |
| 393020-01789 | Simmonds Precision | Fuel Quantity Indicator |
| 393026-001 | Simmonds Precision | Fuel Quantity Indicator |
| 393026-002 | Simmonds Precision | Fuel Quantity Indicator |
| 393026-003 | Simmonds Precision | Fuel Quantity Indicator |
| 393026-01837 | Simmonds Precision | Fuel Quantity Indicator |
| 393026-01838 | Simmonds Precision | Fuel Quantity Indicator |
| 393026-01840 | Simmonds Precision | Fuel Quantity Indicator |
| 393026-01841 | Simmonds Precision | Fuel Quantity Indicator |
| 393026-01880 | Simmonds Precision | Fuel Quantity Indicator |
| 393026-03235 | Simmonds Precision | Fuel Quantity Indicator |
| 393026-052 | Simmonds Precision | Fuel Quantity Indicator |
| 393026-073 | Simmonds Precision | Fuel Quantity Indicator |
| 393026-075 | Simmonds Precision | Fuel Quantity Indicator |
| 393026-077 | Simmonds Precision | Fuel Quantity Indicator |
| 393026-079 | Simmonds Precision | Fuel Quantity Indicator |
| 393026-080 | Simmonds Precision | Fuel Quantity Indicator |

| | | |
|--------------|--------------------|--------------------------------------|
| 393026-081 | Simmonds Precision | Fuel Quantity Indicator |
| 393026-082 | Simmonds Precision | Fuel Quantity Indicator |
| 393026-083 | Simmonds Precision | Fuel Quantity Indicator |
| 393026-084 | Simmonds Precision | Fuel Quantity Indicator |
| 393026-085 | Simmonds Precision | Fuel Quantity Indicator |
| 393026-086 | Simmonds Precision | Fuel Quantity Indicator |
| 393026-087 | Simmonds Precision | Fuel Quantity Indicator |
| 393026-088 | Simmonds Precision | Fuel Quantity Indicator |
| 393026-089 | Simmonds Precision | Fuel Quantity Indicator |
| 393026-091 | Simmonds Precision | Fuel Quantity Indicator |
| 393026-092 | Simmonds Precision | Fuel Quantity Indicator |
| 393026-093 | Simmonds Precision | Fuel Quantity Indicator |
| 393026-094 | Simmonds Precision | Fuel Quantity Indicator |
| 393026-095 | Simmonds Precision | Fuel Quantity Indicator |
| 393026-096 | Simmonds Precision | Fuel Quantity Indicator |
| 393027-002 | Simmonds Precision | Fuel Quantity Indicator |
| 393080-103 | Simmonds Precision | Fuel Quantity Indicator |
| 393080-117 | Simmonds Precision | Fuel Quantity Indicator |
| 393086-01235 | Simmonds Precision | Fuel Quantity Indicator |
| 4006240 | Simmonds Precision | Hydraulic Oil Qty Ind |
| 473048 | Simmonds Precision | Fuel Summation Unit |
| 473383 | Simmonds Precision | Fuel Summation Unit |
| 522-1859-003 | Collins Avionics | Distance Indicator |
| 522-1859-033 | Collins Avionics | Distance Indicator |
| 522-1859-070 | Collins Avionics | Distance Indicator |
| 522-2782-004 | Collins Avionics | Course Indicator |
| 522-2782-034 | Collins Avionics | Course Indicator |
| 522-3120-004 | Collins Avionics | Instrument Amplifier |
| 522-3122-006 | Collins Avionics | Flight Director Indicator |
| 522-3122-010 | Collins Avionics | Flight Director Indicator |
| 522-3138-004 | Collins Avionics | Course Indicator |
| 522-3342-003 | Collins Avionics | Course Indicator |
| 522-3342-005 | Collins Avionics | Course Indicator |
| 522-3487-001 | Collins Avionics | Flight Director Indicator |
| 522-3487-002 | Collins Avionics | Flight Director Indicator |
| 522-3487-003 | Collins Avionics | Flight Director Indicator |
| 522-3487-004 | Collins Avionics | Flight Director Indicator |
| 522-3867-003 | Collins Avionics | Flight Director Indicator |
| 522-4063-003 | Collins Avionics | Flight Director Indicator |
| 522-4114-003 | Collins Avionics | Radio Altitude Indicator |
| 522-4114-006 | Collins Avionics | Radio Altitude Indicator |
| 522-4114-008 | Collins Avionics | Radio Altitude Indicator |
| 522-4363-004 | Collins Avionics | Radio Altitude Indicator |
| 522-4538-002 | Collins Avionics | Aircraft Passenger Address Amplifier |
| 522-4825-001 | Collins Avionics | Radio Altitude Indicator |
| 522-4825-002 | Collins Avionics | Radio Altitude Indicator |
| 522-4825-004 | Collins Avionics | Radio Altitude Indicator |
| 522-4825-006 | Collins Avionics | Radio Altitude Indicator |
| 522-4825-008 | Collins Avionics | Radio Altitude Indicator |
| 540-2 | J.E.T./A.I.M. | Attitude Gyro, Electric, Autopilot |
| 60-1321-1 | Grimes Aerospace | Emergency Exit Light Power Supply |
| 61461 | Horizon Aerospace | Dual Fuel Quantity Indicator |

| | | |
|---------------|--------------------|--------------------------------|
| 6212 | United Instruments | Manifold Pressure Gauge |
| 622-4563-006 | Collins Avionics | Radio Altitude Indicator |
| 622-4563-008 | Collins Avionics | Radio Altitude Indicator |
| 64131-760-1 | Thales/Sextant | Counter/Pointer Altimeter |
| 64141-560-1 | Thales/Sextant | Counter/Pointer Altimeter |
| 651-12-24-15 | Wakmann | Aircraft Clock |
| 705-7V4M1 | Thales/Sextant | Gyroscopic Horizon |
| 705-7V4M1 | Thales/Sextant | Gyroscopic Horizon |
| 711002-3 | Hamilton | Pressure Control Panel |
| 711002-4 | Hamilton | Pressure Control Panel |
| 711002-5 | Hamilton | Pressure Control Panel |
| 772-5005-001 | Collins Avionics | Flight Director Indicator |
| 772-5005-005 | Collins Avionics | Flight Director Indicator |
| 772-5025-001 | Collins Avionics | Horizontal Situation Indicator |
| 772-5025-013 | Collins Avionics | Horizontal Situation Indicator |
| 772-5431-001 | Collins Avionics | Flight Director Indicator |
| 777-1397-003 | Collins Avionics | Horizontal Situation Indicator |
| 777-1397-004 | Collins Avionics | Horizontal Situation Indicator |
| 777-1493-001 | Collins Avionics | ADF Control Unit |
| 777-1493-004 | Collins Avionics | ADF Control Unit |
| 777-1493-005 | Collins Avionics | ADF Control Unit |
| 787-6366-002 | Collins Avionics | ADF Control Unit |
| 787-6366-004 | Collins Avionics | ADF Control Unit |
| 787-6366-005 | Collins Avionics | ADF Control Unit |
| 787-6366-009 | Collins Avionics | ADF Control Unit |
| 787-6385-002 | Collins Avionics | Course Indicator |
| 787-6385-002 | Collins Avionics | Pictorial Navigation System |
| 792-6275-003 | Collins Avionics | ADF Control Unit |
| 792-6275-004 | Collins Avionics | ADF Control Unit |
| 792-6275-005 | Collins Avionics | ADF Control Unit |
| 88000-4102 | Aerosonic | Aircraft Clock |
| 88000-4103 | Aerosonic | Aircraft Clock |
| 88000-4104 | Aerosonic | Aircraft Clock |
| 8DJ125LXC3 | Ametek/G.E. | Flowmeter Indicator |
| 8DJ179KBA2 | Ametek/G.E. | Temperature Indicator |
| 8DJ179KDA1 | Ametek/G.E. | Temperature Indicator |
| 8DJ81LXG2 | Ametek/G.E. | Tachometer Indicator |
| 8DJ81LXH2 | Ametek/G.E. | Tachometer Indicator |
| 8DJ81LYT2 | Ametek/G.E. | Tachometer Indicator |
| 8DJ81LYT4 | Ametek/G.E. | Tachometer Indicator |
| 8DJ81LYV2 | Ametek/G.E. | Tachometer Indicator |
| 8DJ81LYV4 | Ametek/G.E. | Tachometer Indicator |
| 8DJ81WAG2 | Ametek/G.E. | Tachometer Indicator |
| 8DJ81WAG4 | Ametek/G.E. | Tachometer Indicator |
| 8DJ81WBG4 | Ametek/G.E. | Tachometer Indicator |
| 8DJ81WBL4 | Ametek/G.E. | Tachometer Indicator |
| 8DJ81WBM4 | Ametek/G.E. | Tachometer Indicator |
| 8DJ88GAC1 | Ametek/G.E. | Flowmeter Indicator |
| 8DJ88LWX3 | Ametek/G.E. | Flowmeter Indicator |
| A42899-10-016 | Kollsman | Servoed Altimeter |
| A42899-10-216 | Kollsman | Servoed Altimeter |
| B0063-81101 | Smiths/Astek | Counter Pointer Drum Altimeter |

| | | |
|---------------|--------------------|-------------------------------------|
| B0063-81107 | Smiths/Astek | Counter Pointer Drum Altimeter |
| B0063-81108 | Smiths/Astek | Counter Pointer Drum Altimeter |
| B0063-81114 | Smiths/Astek | Counter Pointer Drum Altimeter |
| B0243-81132 | Smiths/Astek | Mach Airspeed Indicator |
| B0247-81107 | Smiths/Astek | Mach Airspeed Indicator |
| B0248-81105 | Smiths/Astek | Mach Airspeed Indicator |
| B0652-71104-1 | Smiths/Astek | Altitude Alerting Control |
| B0704-10004 | Smiths/Astek | Overspeed Limit Sensor |
| B0704-10006 | Smiths/Astek | Mach Airspeed Warning Switch |
| B0704-10008 | Smiths/Astek | Overspeed Limit Sensor |
| B0704-10009 | Smiths/Astek | Mach Airspeed Warning Switch |
| B0704-10010 | Smiths/Astek | Overspeed Limit Sensor |
| B0704-10011 | Smiths/Astek | Mach Airspeed Indicator |
| B0704-10012 | Smiths/Astek | Overspeed Limit Sensor |
| B0704-10016 | Smiths/Astek | Overspeed Limit Sensor |
| B0704-10037 | Smiths/Astek | Overspeed Limit Sensor |
| B0704-10042 | Smiths/Astek | Overspeed Limit Sensor |
| B0707-10001 | Smiths/Astek | Mach Airspeed Warning Switch |
| B0707-10008 | Smiths/Astek | Overspeed Limit Sensor |
| B1800-81103 | Smiths/Astek | Servoed Altitude Indicator |
| B1800-81108 | Smiths/Astek | Servoed Altitude Indicator |
| B711-1 | Simmonds Precision | Hydraulic Oil Qty Ind |
| B712-1 | Simmonds Precision | Hydraulic Oil Qty Ind |
| B712-2 | Simmonds Precision | Hydraulic Oil Qty Ind |
| B712-4 | Simmonds Precision | Hydraulic Oil Qty Ind |
| BPS7-3 | Radiant Power Corp | Battery Power Supply |
| C-5C | Ametek/U.S. Gauge | Pilots Standby Compass |
| C-5C | Honeywell/Sperry | Directional Gyro Indicator |
| EA100ANH-153H | Simmonds Precision | Hydraulic Oil Quantity Indicator |
| FDS765A-1 | Nohmi | Smoke Sensor |
| FDS765A-2 | Nohmi | Smoke Sensor |
| G9325A1 | Grimes Aerospace | Navigational Rotating Warning Light |
| G9325A2 | Grimes Aerospace | Navigational Rotating Warning Light |
| H321AAM1 | Thales/Sextant | Gyroscopic Horizon |
| H321ABM1 | Thales/Sextant | Gyroscopic Horizon |
| H321ACM1 | Thales/Sextant | Gyroscopic Horizon |
| H321AFM1 | Thales/Sextant | Gyroscopic Horizon |
| H321AGM1 | Thales/Sextant | Gyroscopic Horizon |
| H321AKM1 | Thales/Sextant | Gyroscopic Horizon |
| H321AMM1 | Thales/Sextant | Gyroscopic Horizon |
| H321ANM1 | Thales/Sextant | Gyroscopic Horizon |
| H321AQM1 | Thales/Sextant | Gyroscopic Horizon |
| H321ASM1 | Thales/Sextant | Gyroscopic Horizon |
| H321AYM1 | Thales/Sextant | Gyroscopic Horizon |
| H321AZM1 | Thales/Sextant | Gyroscopic Horizon |
| H321BAM1 | Thales/Sextant | Gyroscopic Horizon |
| H321BDM1 | Thales/Sextant | Gyroscopic Horizon |
| H321BEM2 | Thales/Sextant | Gyroscopic Horizon |
| H321BFM2 | Thales/Sextant | Gyroscopic Horizon |
| H321BGM1 | Thales/Sextant | Gyroscopic Horizon |
| H321BNM | Thales/Sextant | Gyroscopic Horizon |
| H321CCM | Thales/Sextant | Gyroscopic Horizon |

| | | |
|----------------|---------------------|---|
| JG298A5 | Honeywell/Sperry | Pressure Ratio Indicator |
| LK-35-3 | TKK | Standby Altimeter |
| LK-35-4 | TKK | Standby Altimeter |
| SLZ9123 | Avionic Specialties | Inertial-Lead Vertical Speed Indicator |
| SLZ9145 | Avionic Specialties | Inertial-Lead Vertical Speed Indicator |
| SLZ9190 | Avionic Specialties | Inertial-Lead Vertical Speed Indicator |
| SRDL-6D | Ametek/U.S. Gauge | Dual Indicator |
| SRDL-7G | Ametek/U.S. Gauge | Dual Indicator |
| SRDL-7H | Ametek/U.S. Gauge | Hydraulic System Pressure Indicator, Dual |
| ST-106AB | Ametek/U.S. Gauge | Pressure Transmitter |
| ST-107R | Ametek/U.S. Gauge | Transmitter, Pressure, Hydraulic |
| ST-7R | Ametek/U.S. Gauge | Pressure Transmitter |
| WL/1103AM/MS/2 | Smiths Industries | Servo Altimeter |
| WL/1103AM/MS/3 | Smiths Industries | Servo Altimeter |
| WL/202EED3 | Smiths Industries | Temperature Indicator |
| WL/202EED4 | Smiths Industries | Temperature Indicator |
| WL/504CUF/EA/1 | Smiths Industries | Altitude Alerting Unit |
| WL/509CUF/EA/1 | Smiths Industries | Altitude Alerting Unit |
| WL/804AM/CP/1 | Smiths Industries | Mechanical Counter-Pointer Altimeter |
| WL/808AM/EA/2 | Smiths Industries | Mechanical Counter-Pointer Altimeter |
| WL101EED2 | Smiths Industries | N1% RPM Indicator |
| WL101EED3 | Smiths Industries | N1% RPM Indicator |
| WL102AMS1 | Smiths Industries | Altimeter/Airspeed Indicator |
| WL102AMS2 | Smiths Industries | Altimeter/Airspeed Indicator |
| WL102AMS3 | Smiths Industries | Altimeter/Airspeed Indicator |